






























UDG[®]
UDGGEAR.COM



EQUIPMENT COMPATIBILITY GUIDE

EDITION
02/2020

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U8007BL3 WHEELED LAPTOP BACKPACK BLACK 21"</p>  <p>35 (W) x 51 (H) x 8 (D) cm 13.7 x 20.1 x 3.1 inch</p>	<p>DENON PRIME GO NEW</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>NI TRAKTOR S2 MK3</p>  <p>48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch</p>	<p>PIONEER DDJ-XP2 NEW</p>  <p>33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch</p>	<p>PIONEER DDJ-200</p>  <p>37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch</p>	<p>PIONEER DDJ-WeGO4</p>  <p>38 (W) x 24 (H) x 5.9 (D) cm 14.9 x 9.5 x 2.3 inch</p>
<p>U8015BL WHEELED MIDI CONTROLLER CASE 21"</p>  <p>NEW</p> <p>36 (W) x 56 (H) x 10.5 (D) cm 14.2 x 22 x 4.1 inch</p>	<p>DENON PRIME GO NEW</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>DENON MC4000</p>  <p>50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch</p>	<p>NI TRAKTOR S3 NEW</p>  <p>54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch</p>	<p>NI TRAKTOR S4 MK3</p>  <p>54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch</p>	<p>NI TRAKTOR S2 MK3</p>  <p>48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch</p>
<p>U8301BL CONTROLLER HARDCASE MEDIUM BLACK MK2</p>  <p>47 (W) x 34 (H) x 7.8 (D) cm 18.5 x 13.4 x 3.1 inch</p>	<p>DENON PRIME GO NEW</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>PIONEER DDJ-200</p>  <p>37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch</p>	<p>PIONEER DDJ-WeGO4</p>  <p>38 (W) x 24 (H) x 5.9 (D) cm 14.9 x 9.5 x 2.3 inch</p>	<p>PIONEER TORAIZ SP-16</p>  <p>43.7 (W) x 26.1 (H) x 7.5 (D) cm 17.2 x 10.3 x 2.9 inch</p>	<p>AKAI APC40 MKII</p>  <p>42.4 (W) x 25.4 (H) x 4.6 (D) cm 16.6 x 10 x 1.8 inch</p>
<p>U8302BL CONTROLLER HARDCASE LARGE BLACK MK2</p>  <p>59.3 (W) x 35.3 (H) x 8.4 (D) cm 23.3 x 13.9 x 3.3 inch</p>	<p>NOVATION BASS STATION 2</p>  <p>45.7 (W) x 27.3 (H) x 7.6 (D) cm 17.9 x 10.7 x 2.9 inch</p>	<p>RELOOP BEATMIX 2 MK2</p>  <p>49.2 (W) x 31.7 (H) x 3.5 (D) cm 19.3 x 12.5 x 1.4 inch</p>	<p>RELOOP BEATPAD2</p>  <p>46 (W) x 32.5 (H) x 4.2 (D) cm 18.1 x 12.8 x 1.65 inch</p>	<p>ROLAND TR-8S</p>  <p>40.9 (W) x 26.3 (H) x 5.8 (D) cm 16.1 x 10.3 x 2.3 inch</p>	<p>ROLAND TR-8</p>  <p>40 (W) x 26 (H) x 6.5 (D) cm 15.7 x 10.2 x 2.5 inch</p>
	<p>NI TRAKTOR S3 NEW</p>  <p>54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch</p>	<p>NI TRAKTOR S4 MK3</p>  <p>54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch</p>	<p>NI TRAKTOR S2 MK3</p>  <p>48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch</p>	<p>DENON MC4000</p>  <p>50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch</p>	<p>ROLAND DJ-707M NEW</p>  <p>47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch</p>
	<p>PIONEER DDJ-400</p> <p>48.5 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SB3</p> <p>48.3 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SR2</p> <p>55.3 (W) x 33.5 (H) x 6.5 (D) cm 21.8 x 13.2 x 2.6 inch</p>	<p>ARTURIA KEYSTEP PRO NEW</p> <p>58.9 (W) x 20.8 (H) x 3.8 (D) cm 23.2 x 8.2 x 1.5 inch</p>	<p>MIXARS PRIMO</p> <p>50.9 (W) x 33.1 (H) x 6.6 (D) cm 20 x 13 x 2.6 inch</p>

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U8303BL CONTROLLER HARDCASE EXTRA LARGE BLACK MK2</p>  <p>71.5 (W) x 41.5 (H) x 8.4 (D) cm 28.2 x 16.3 x 3.3 inch</p>	<p>PIONEER DDJ-800</p>  <p>63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch</p>	<p>PIONEER XDJ-RR</p>  <p>62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch</p>	<p>PIONEER DDJ-1000SRT</p>  <p>70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch</p>	<p>PIONEER DDJ-SX3</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>NUMARK NS6II</p>  <p>60 (W) x 33 (D) x 6.7 (D) cm 23.6 x 13 x 2.6 inch</p>
<p>U8304BL CONTROLLER HARDCASE 2XL MK2</p>  <p>91.1 (W) x 48 (H) x 8.5 (D) cm 35.9 x 18.9 x 3.4 inch</p>	<p>PIONEER DDJ-RZ</p>  <p>87 (W) x 42 (H) x 9.84 (D) cm 34.3 x 16.5 x 3.9 inch</p>		<p>PIONEER DDJ-SZ2</p>  <p>87 (W) x 42 (H) x 9.8 (D) cm 34.3 x 16.5 x 3.9 inch</p>		
<p>U8305BL PIONEER DDJ-1000/ XDJ-RX2/ DENON MCX8000/ ROLAND DJ 808 HARDCASE</p>  <p>76.2 (W) x 45.7 (H) x 12.1 (D) cm 30 x 18 x 4.7 inch</p>	<p>PIONEER DDJ-1000SRT</p>  <p>70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch</p>	<p>PIONEER XDJ-RX2</p>  <p>72.8 (W) x 44.4 (H) x 10.8 (D) cm 28.6 x 17.5 x 4.2 inch</p>	<p>DENON MCX8000</p>  <p>72.8 (W) x 43.3 (H) x 7 (D) cm 28.6 x 17 x 2.7 inch</p>	<p>ROLAND DJ-808</p>  <p>66.8 (W) x 42.7 (H) x 8.4 (D) cm 26.3 x 16.8 x 3.3 inch</p>	
<p>U8306BL 49 KEYBOARD HARDCASE</p>  <p>88 (W) x 30 (H) x 11 (D) cm 34.6 x 11.8 x 4.3 inch</p>	<p>NI KOMPLETE KONTROL S49 MK2</p>  <p>84 (W) x 29.7 (H) x 8.4 (D) cm 33.1 x 11.7 x 3.3 inch</p>	<p>NI KOMPLETE KONTROL A49</p>  <p>82 (W) x 25.7 (H) x 8.9 (D) cm 32.3 x 10.1 x 3.5 inch</p>	<p>AKAI ADVANCE 49</p>  <p>75 (W) x 29.3 (H) x 8.8 (D) cm 29.5 x 11.5 x 3.5 inch</p>	<p>AKAI MPK249</p>  <p>73.7 (W) x 29.8 (H) x 9.2 (D) cm 29 x 12.3 x 3.4 inch</p>	<p>KORG MICROSTATION</p>  <p>77.8 (W) x 21 (H) x 8.2 (D) cm 30.6 x 8.2 x 3.2 inch</p>
<p>NOVATION 49SL MKIII</p>  <p>80.3 (W) x 29.3 (H) x 6.8 (D) cm 31.6 x 11.5 x 2.6 inch</p>	<p>NOVATION LAUNCHKEY 49</p>  <p>77.5 (W) x 27 (H) x 9 (D) cm 30.5 x 10.6 x 3.5 inch</p>	<p>M-AUDIO CODE 49</p>  <p>86 (W) x 25.5 (H) x 7.1 (D) cm 33.9 x 10 x 2.8 inch</p>	<p>M-AUDIO OXYGEN 49 MK IV</p>  <p>73.7 (W) x 23.9 (H) x 9.4 (D) cm 29 x 9.4 x 3.7 inch</p>	<p>ARTURIA KEYLAB ESSENTIAL 49</p>  <p>78.4 (W) x 24.8 (H) x 7.6 (D) cm 30.9 x 9.7 x 2.9 inch</p>	










UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U8307BL 61 KEYBOARD HARDCASE</p>  <p>106 (W) x 42 (H) x 13.8 (D) cm 41.7 x 16.5 x 5.4 inch</p>	<p>NI KOMPLETE KONTROL A61</p>  <p>98.4 (W) x 25.7 (H) x 8.9 (D) cm 38.7 x 10.1 x 3.5 inch</p>	<p>KORG Pa700</p>  <p>103 (W) x 37.8 (H) x 13.3 (D) cm 40.5 x 14.9 x 5.2 inch</p>	<p>KORG Pa1000</p>  <p>103 (W) x 37.8 (H) x 13.3 (D) cm 40.5 x 14.9 x 5.2 inch</p>	<p>AKAI ADVANCE 61</p>  <p>91.4 (W) x 29.3 (H) x 8.8 (D) cm 36 x 11.5 x 3.5 inch</p>	<p>AKAI MPK261</p>  <p>90.5 (W) x 29.8 (H) x 9.2 (D) cm 35.63 x 12.3 x 3.4 inch</p>
<p>U8308BL TURNTABLE HARDCASE</p>  <p>46 (W) x 37.5 (H) x 17 (D) cm 18.1 x 14.7 x 6.7 inch</p>	<p>RELOOP RP-8000 MK2</p>  <p>45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch</p>	<p>RELOOP RP-7000 MK2</p>  <p>45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch</p>	<p>AUDIOTECHNICALP120XUSB</p>  <p>45.2 (W) x 35.2 (H) x 14.2 (D) cm 17.8 x 13.8 x 5.6 inch</p>	<p>AUDIOTECHNICALPW40WN</p>  <p>42 (W) x 34 (H) x 11.7 (D) cm 16.5 x 13.4 x 4.6 inch</p>	<p>TECHNICS SL-1210GR</p>  <p>45.3 (W) x 37.2 (H) x 17.3 (D) cm 17.8 x 14.6 x 6.8 inch</p>
<p>U8443BL CDJ/ DJM/ BATTLE MIXER HARDCASE</p>  <p>42 (W) x 35 (H) x 13.5 (D) cm 16.5 x 13.8 x 5.3 inch</p>	<p>PIONEER DJS-1000</p>  <p>42.2 (W) x 32 (H) x 11 (D) cm 16.6 x 12.5 x 4.3 inch</p>	<p>PIONEER DJM-S3</p>  <p>32 (W) x 23 (H) x 10.8 (D) cm 12.5 x 9 x 4.3 inch</p>	<p>PIONEER XDJ-1000MK2</p>  <p>30.5 (W) x 38.3 (H) x 11 (D) cm 12 x 15.1 x 4.3 inch</p>	<p>PIONEER DJM-900NXS2</p>  <p>41.4 (W) x 33.3 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch</p>	<p>PIONEER CDJ-2000NXS2</p>  <p>41.4 (W) x 32 (H) x 11.3 (D) cm 15.9 x 12.5 x 4.4 inch</p>
<p>U7002BL MIDI CONTROLLER FLIGHTBAG LARGE</p>  <p>70 (W) x 40 (H) x 11 (D) cm 27.6 x 15.7 x 4.3 inch</p>	<p>PIONEER DDJ-800</p>  <p>63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch</p>	<p>PIONEER XDJ-RR</p>  <p>62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch</p>	<p>PIONEER DDJ-SX3</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>PIONEER DDJ-1000SRT</p>  <p>70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch</p>	<p>RELOOP MIXON 4</p>  <p>65.7 (W) x 37.6 (H) x 4.5 (D) cm 25.8 x 14.8 x 1.8 inch</p>
<p>NI TRAKTOR S3</p>  <p>54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch</p>	<p>NI TRAKTOR S4 MK3</p>  <p>54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch</p>	<p>NI TRAKTOR S8</p>  <p>58.5 (W) x 38.7 (H) x 6.6 (D) cm 23 x 15.2 x 2.6 inch</p>	<p>RELOOP TOUCH</p>  <p>59.4 (W) x 37.7 (H) x 4.3 (D) cm 23.4 x 14.8 x 1.7 inch</p>	 <p>17" laptop and small gears</p>	

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U7101BL MIDI CONTROLLER SLEEVE MEDIUM</p>  <p>53 (W) x 34 (H) x 9 (D) cm 20.8 x 13.4 x 3.5 inch</p>	<p>PIONEER DDJ-400</p>  <p>48.5 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SB3</p>  <p>48.3 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-RB</p>  <p>48.2 (W) x 27.2 (H) x 5.9 (D) cm 18.9 x 10.7 x 2.3 inch</p>	<p>NI TRAKTOR S2 MK3</p>  <p>48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch</p>	<p>ROLAND DJ-707M NEW</p>  <p>47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch</p>
<p>U7102BL MIDI CONTROLLER SLEEVE LARGE</p>  <p>70 (W) x 40 (H) x 11 (D) cm 27.6 x 15.7 x 4.3 inch</p>	<p>PIONEER DDJ-800</p>  <p>63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch</p>	<p>PIONEER XDJ-RR</p>  <p>62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch</p>	<p>PIONEER DDJ-SX3</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>PIONEER DDJ-1000SRT</p>  <p>70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch</p>	<p>PIONEER DDJ-SR2</p>  <p>55.3 (W) x 33.5 (H) x 6.5 (D) cm 21.8 x 13.2 x 2.6 inch</p>
<p>U7103BL MIDI CONTROLLER SLEEVE EXTRA LARGE</p>  <p>89.2 (W) x 46.2 (H) x 10.5 (D) cm 35.1 x 18.2 x 4.1 inch</p>	<p>PIONEER XDJ-XZ NEW</p>  <p>87.8 (W) x 46.6 (H) x 11.8 (D) cm 34.5 x 18.3 x 4.6 inch</p>	<p>PIONEER XDJ-RX2</p>  <p>72.8 (W) x 44.4 (H) x 10.8 (D) cm 28.6 x 17.5 x 4.2 inch</p>	<p>PIONEER DDJ-RZ</p>  <p>87 (W) x 42 (H) x 9.84 (D) cm 34.3 x 16.5 x 3.9 inch</p>	<p>PIONEER DDJ-SZ2</p>  <p>87 (W) x 42 (H) x 9.8 (D) cm 34.3 x 16.5 x 3.9 inch</p>	
<p>U7201BL MIDI CONTROLLER BACKPACK MEDIUM BLACK</p>  <p>56 (W) x 37 (H) x 9 (D) cm 22 x 14.6 x 3.5 inch</p>	<p>NI TRAKTOR S3 NEW</p>  <p>54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch</p>	<p>NI TRAKTOR S4 MK3</p>  <p>54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch</p>	<p>NI TRAKTOR S2 MK3</p>  <p>48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch</p>	<p>PIONEER DDJ-400</p>  <p>48.5 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SB3</p>  <p>48.3 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>
	<p>DENON PRIME GO NEW</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>DENON MC4000</p>  <p>50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch</p>	<p>RELOOP BEATMIX 4 MK2</p>  <p>55.8 (W) x 31.7 (H) x 4.1 (D) cm 21.9 x 12.5 x 1.6 inch</p>	<p>MIXARS PRIMO</p>  <p>50.9 (W) x 33.1 (H) x 6.6 (D) cm 20 x 13 x 2.6 inch</p>	 <p>15.4" laptop and small gears</p>

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U7202BL MIDI CONTROLLER BACKPACK LARGE BLACK</p>  <p>70 (W) x 40 (H) x 10 (D) cm 27.6 x 15.7 x 3.9 inch</p>	<p>PIONEER DDJ-800</p>  <p>63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch</p>	<p>PIONEER XDJ-RR</p>  <p>62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch</p>	<p>PIONEER DDJ-1000SRT</p>  <p>70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch</p>	<p>PIONEER DDJ-SX3</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>DENON MC7000</p>  <p>66.4 (W) x 37.8 (H) x 6.8 (D) cm 26.1 x 14.9 x 2.7 inch</p>
<p>U7203BL MIDI CONTROLLER BACKPACK EXTRA LARGE BLACK</p>  <p>73.3 (W) x 50.1 (H) x 10.2 (D) cm 28.9 x 19.7 x 4 inch</p>	<p>DENON PRIME 4</p>  <p>72.9 (W) x 49.7 (H) x 10.4 (D) cm 28.7 x 19.5 x 4.1 inch</p>	<p>DENON MCX8000</p>  <p>72.8 (W) x 43.3 (H) x 7 (D) cm 28.6 x 17 x 2.7 inch</p>	<p>PIONEER XDJ-RX2</p>  <p>72.8 (W) x 44.4 (H) x 10.8 (D) cm 28.6 x 17.5 x 4.2 inch</p>	<p>ROLAND DJ-808</p>  <p>66.8 (W) x 42.7 (H) x 8.4 (D) cm 26.3 x 16.8 x 3.3 inch</p>	
<p>U9022BL/OR PRODUCER BAG LARGE BLACK, ORANGE INSIDE</p>  <p>32 (W) x 46.5 (H) x 15 (D) cm 12.6 x 18.3 x 5.9 inch</p>	<p>DENON PRIME GO</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>PIONEER DDJ-XP2</p>  <p>33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch</p>	<p>PIONEER DDJ-200</p>  <p>37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch</p>	<p>NOVATION LAUNCHKEY MINI MKIII</p>  <p>33 (W) x 17.2 (H) x 3.1 (D) cm 12.9 x 6.7 x 1.2 inch</p>	<p>HERCULES DJCONTROL JOGVISION</p>  <p>45.5 (W) x 25.4 (H) x 8.5 (D) cm 17.9 x 10 x 3.3 inch</p>
<p>U9101BL/OR DIGI BACKPACK BLACK, ORANGE INSIDE</p>  <p>30 (W) x 42 (H) x 13 (D) cm 11.8 x 16.5 x 5.1 inch</p>	<p>PIONEER DDJ-XP2</p>  <p>33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch</p>	<p>PIONEER DDJ-200</p>  <p>37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch</p>	<p>PIONEER TORAIZ SQUID</p>  <p>37.5 (W) x 22.4 (H) x 7.2 (D) cm 14.7 x 8.8 x 2.8 inch</p>	<p>NI MASCHINE MIKRO MK3</p>  <p>32 (W) x 17.7 (H) x 4.5 (D) cm 12.6 x 6.9 x 1.7 inch</p>	<p>RELOOP SPIN</p>  <p>37 (W) x 26 (H) x 9.5 (D) cm 14.6 x 10.2 x 3.7 inch</p>
	<p>NOVATION LAUNCHKEY MINI MKIII</p>  <p>33 (W) x 17.2 (H) x 3.1 (D) cm 12.9 x 6.7 x 1.2 inch</p>	<p>NOVATION LAUNCHPAD PRO MK3</p>  <p>26.8 (W) x 26.8 (H) x 1.8 (D) cm 10.5 x 10.5 x 0.7 inch</p>	<p>NUMARK PT01 SCRATCH</p>  <p>30.2 (W) x 30.2 (H) x 10.2 (D) cm 11.9 x 11.9 x 4 inch</p>	<p>HERCULES DJCONTROL STARLIGHT</p>  <p>34 (W) x 10 (H) x 4.9 (D) cm 13.4 x 3.9 x 1.9 inch</p>	<p>15.4" laptop and small gears</p>























UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U9102BL/OR BACKPACK BLACK, ORANGE INSIDE</p>  <p>33 (W) x 40 (H) x 14 (D) cm 13 x 15.7 x 5.5 inch</p>	<p>PIONEER DDJ-XP2 NEW</p>  <p>33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch</p>	<p>PIONEER DDJ-200</p>  <p>37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch</p>	<p>PIONEER TORAIZ SQUID</p>  <p>37.5 (W) x 22.4 (H) x 7.2 (D) cm 14.7 x 8.8 x 2.8 inch</p>	<p>NI MASCHINE MIKRO MK3 NEW</p>  <p>32 (W) x 17.7 (H) x 4.5 (D) cm 12.6 x 6.9 x 1.7 inch</p>	<p>RELOOP SPIN</p>  <p>37 (W) x 26 (H) x 9.5 (D) cm 14.6 x 10.2 x 3.7 inch</p>
<p>U9103BL/OR MIDI CONTROLLER BACKPACK SMALL MK2 BLACK/ORANGE</p>  <p>55.5 (W) x 35 (H) x 12 (D) cm 21.7 x 13.8 x 4.7 inch</p>	<p>DENON PRIME GO NEW</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>DENON MC4000</p>  <p>50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch</p>	<p>PIONEER DDJ-400</p>  <p>48.5 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SB3</p>  <p>48.3 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>ROLAND DJ-707M NEW</p>  <p>47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch</p>
<p>U9104BL/OR MIDI CONTROLLER BACKPACK LARGE MK2 BLACK/ORANGE</p>  <p>68.5 (W) x 39 (H) x 13 (D) cm 26.9 x 15.4 x 5.1 inch</p>	<p>PIONEER DDJ-800</p>  <p>63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch</p>	<p>PIONEER XDJ-RR</p>  <p>62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch</p>	<p>PIONEER DDJ-SX3</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>DENON MC7000</p>  <p>66.4 (W) x 37.8 (H) x 6.8 (D) cm 26.1 x 14.9 x 2.7 inch</p>	<p>NUMARK NS6II</p>  <p>60 (W) x 33 (D) x 6.7 (D) cm 23.6 x 13 x 2.6 inch</p>
<p>U9108BL/OR BACKPACK SLIM BLACK, ORANGE INSIDE</p>  <p>33 (W) x 40 (H) x 14 (D) cm 13 x 15.7 x 5.5 inch</p>	<p>PIONEER DDJ-XP2 NEW</p>  <p>33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch</p>	<p>PIONEER DDJ-200</p>  <p>37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch</p>	<p>PIONEER TORAIZ SQUID</p>  <p>37.5 (W) x 22.4 (H) x 7.2 (D) cm 14.7 x 8.8 x 2.8 inch</p>	<p>NI MASCHINE MIKRO MK3 NEW</p>  <p>32 (W) x 17.7 (H) x 4.5 (D) cm 12.6 x 6.9 x 1.7 inch</p>	<p>RELOOP SPIN</p>  <p>37 (W) x 26 (H) x 9.5 (D) cm 14.6 x 10.2 x 3.7 inch</p>
	<p>NOVATION LAUNCHKEY MINI MKIII NEW</p>  <p>33 (W) x 17.2 (H) x 3.1 (D) cm 12.9 x 6.7 x 1.2 inch</p>	<p>NOVATION LAUNCHPAD PRO MK3 NEW</p>  <p>26.8 (W) x 26.8 (H) x 1.8 (D) cm 10.5 x 10.5 x 0.7 inch</p>	<p>NUMARK PTO1 SCRATCH</p>  <p>30.2 (W) x 30.2 (H) x 10.2 (D) cm 11.9 x 11.9 x 4 inch</p>	<p>HERCULES DJCONTROL STARLIGHT</p>  <p>34 (W) x 10 (H) x 4.9 (D) cm 13.4 x 3.9 x 1.9 inch</p>	<p>15.4" laptop and small gears</p> 

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U9013 MIDI CONTROLLER SLINGBAG LARGE MK2 BLACK/ORANGE</p>  <p>58.5 (W) x 38.7 (H) x 9 (D) cm 23 x 15.2 x 3.5 inch</p>	<p>DENON PRIME GO NEW</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>DENON MC4000</p>  <p>50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch</p>	<p>PIONEER DDJ-400</p>  <p>48.5 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SB3</p>  <p>48.3 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>ROLAND DJ-707M NEW</p>  <p>47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch</p>
<p>U91014BL3 / U92014SL FLIGHT CASE MULTI FORMAT XXL PLUS (LAPTOP SHELF)</p>  <p>73 (W) x 42 (H) x 5.3 (D) cm 28.7 x 16.5 x 2.1 inch</p>	<p>PIONEER DDJ-800</p>  <p>63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch</p>	<p>PIONEER XDJ-RR</p>  <p>62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch</p>	<p>PIONEER DDJ-SX3</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>PIONEER DDJ-1000SRT</p>  <p>70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch</p>	<p>AKAI MPC X</p>  <p>50.5 (W) x 42.5 (H) x 8.8 (D) cm 19.9 x 16.7 x 3.4 inch</p>
<p>U91019BL3 / U92019SL FLIGHT CASE MULTI FORMAT XL PLUS (LAPTOP SHELF)</p>  <p>55.5 (W) x 33.7 (H) x 4.5 (D) cm 21.8 x 13.3 x 1.8 inch</p>	<p>DENON PRIME GO NEW</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>DENON MC4000</p>  <p>50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch</p>	<p>PIONEER DDJ-400</p>  <p>48.5 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SB3</p>  <p>48.3 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>ROLAND DJ-707M NEW</p>  <p>47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch</p>
<p>U91021BL2 / U92021SL FLIGHT CASE MULTI FORMAT CDJ / MIXER II</p>  <p>33.5 (W) x 48.6 (D) x 7.4 (D) cm 13.1 x 19.1 x 2.9 inch</p>	<p>DENON SC6000 PRIME NEW</p>  <p>46.3 (W) x 32 (H) x 15.1 (D) cm 18.2 x 12.6 x 5.9 inch</p>	<p>DENON X1850 PRIME NEW</p>  <p>44.8 (W) x 30.9 (H) x 11 (D) cm 17.6 x 12.2 x 4.3 inch</p>	<p>DENON SC5000 PRIME</p>  <p>32 (W) x 41.9 (H) x 13.5 (D) cm 12.6 x 16.5 x 5.3 inch</p>	<p>DENON X1800 PRIME</p>  <p>30.9 (W) x 43.4 (H) x 8.9 (D) cm 12.2 x 17.1 x 3.5 inch</p>	<p>RELOOP ELITE</p>  <p>41.4 (W) x 29 (H) x 10.8 (D) cm 16.3 x 11.4 x 4.3 inch</p>
<p>33.5 (W) x 48.6 (D) x 7.4 (D) cm 13.1 x 19.1 x 2.9 inch</p>	<p>PIONEER XDJ-1000MK2</p>  <p>30.5 (W) x 38.3 (H) x 11 (D) cm 12 x 15.1 x 4.3 inch</p>	<p>PIONEER DJM-900NXS</p>  <p>41.4 (W) x 33.3 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch</p>	<p>PIONEER CDJ-2000NXS</p>  <p>41.4 (W) x 32 (H) x 11.3 (D) cm 15.9 x 12.5 x 4.4 inch</p>	<p>RANE SEVENTY NEW</p>  <p>44.5 (W) x 28.5 (H) x 10.5 (D) cm 17.5 x 11.2 x 4.1 inch</p>	<p>RANE SEVENTY-TWO</p>  <p>44.5 (W) x 28 (H) x 9 (D) cm 17.5 x 11 x 3.5 inch</p>

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U91030BL2 / U92030SL / U91029BL2 / U92029SL FLIGHT CASE MULTI FORMAT TURNTABLE / PLUS (TROLLEY & WHEELS)</p>  <p>45.5 (W) x 36.5 (H) x 8.4 (D) cm 17.9 x 14.4 x 3.3 inch</p>	<p>RELOOP RP-8000 MK2</p>  <p>45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch</p>	<p>RELOOP RP-7000 MK2</p>  <p>45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch</p>	<p>AUDIOTECHNICAL P120XUSB</p>  <p>45.2 (W) x 35.2 (H) x 14.2 (D) cm 17.8 x 13.8 x 5.6 inch</p>	<p>AUDIOTECHNICAL LPW40WN</p>  <p>42 (W) x 34 (H) x 11.7 (D) cm 16.5 x 13.4 x 4.6 inch</p>	<p>TECHNICS SL-1210GR</p>  <p>45.3 (W) x 37.2 (H) x 17.3 (D) cm 17.8 x 14.6 x 6.8 inch</p>
<p>U91054BL / U92054SL FLIGHT CASE MULTI FORMAT XXL PLUS (LAPTOP SHELF + TROLLEY + WHEELS)</p>  <p>73 (W) x 42 (H) x 5.3 (D) cm 28.7 x 16.5 x 2.1 inch</p>	<p>TECHNICS SL-1200 MK7</p>  <p>45.3 (W) x 35.3 (H) x 16.9 (D) cm 17.8 x 13.9 x 6.6 inch</p>	<p>PIONEER PLX-1000</p>  <p>45.3 (W) x 35.3 (H) x 15.9 (D) cm 17.8 x 13.8 x 6.3 inch</p>	<p>DENON VL12 PRIME</p>  <p>45.1 (W) x 35.5 (H) x 15 (D) cm 17.7 x 13.9 x 5.9 inch</p>	<p>STANTON STR8.150 M2</p>  <p>45 (W) x 35.3 (H) x 14.6 (D) cm 17.7 x 13.9 x 5.7 inch</p>	<p>VESTAX PDX-3000MKII</p>  <p>45.4 (W) x 36.5 (H) x 16.2 (D) cm 17.9 x 14.3 x 6.4 inch</p>
<p>U91059BL / U92059SL FLIGHT CASE MULTI FORMAT XL PLUS (LAPTOP SHELF + TROLLEY + WHEELS)</p>  <p>55.5 (W) x 33.7 (H) x 4.5 (D) cm 21.8 x 13.3 x 1.8 inch</p>	<p>PIONEER DDJ-800</p>  <p>63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch</p>	<p>PIONEER XDJ-RR</p>  <p>62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch</p>	<p>PIONEER DDJ-SX3</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>PIONEER DDJ-1000SRT</p>  <p>70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch</p>	<p>AKAI MPC X</p>  <p>50.5 (W) x 42.5 (H) x 8.8 (D) cm 19.9 x 16.7 x 3.4 inch</p>
<p>U93010 PICK FOAM FLIGHT CASE MULTI FORMAT S</p>  <p>39.1 (W) x 31.1 (D) x 18.5 (D) cm 15.4 x 12.2 x 7.3 inch</p>	<p>DENON MC7000</p>  <p>66.4 (W) x 37.8 (H) x 6.8 (D) cm 26.1 x 14.9 x 2.7 inch</p>	<p>RELOOP MIXON 4</p>  <p>65.7 (W) x 37.6 (H) x 4.5 (D) cm 25.8 x 14.8 x 1.8 inch</p>	<p>RELOOP TOUCH</p>  <p>59.4 (W) x 37.7 (H) x 4.3 (D) cm 23.4 x 14.8 x 1.7 inch</p>	<p>NI TRAKTOR KONTROL S8</p>  <p>58.5 (W) x 38.7 (H) x 6.6 (D) cm 23 x 15.2 x 2.6 inch</p>	<p>18.4"</p>  <p>18.4" laptop and small gears</p>
<p>U91059BL / U92059SL FLIGHT CASE MULTI FORMAT XL PLUS (LAPTOP SHELF + TROLLEY + WHEELS)</p>  <p>55.5 (W) x 33.7 (H) x 4.5 (D) cm 21.8 x 13.3 x 1.8 inch</p>	<p>DENON PRIME GO</p>  <p>41.1 (W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>DENON MC4000</p>  <p>50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch</p>	<p>PIONEER DDJ-400</p>  <p>48.5 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SB3</p>  <p>48.3 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>ROLAND DJ-707M</p>  <p>47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch</p>
<p>U93010 PICK FOAM FLIGHT CASE MULTI FORMAT S</p>  <p>39.1 (W) x 31.1 (D) x 18.5 (D) cm 15.4 x 12.2 x 7.3 inch</p>	<p>NI TRAKTOR S3</p>  <p>54.4 (W) x 31.6 (H) x 6.2 (D) cm 21.4 x 12.4 x 2.4 inch</p>	<p>NI TRAKTOR S4 MK3</p>  <p>54.2 (W) x 33.9 (H) x 6.1 (D) cm 21.3 x 13.3 x 2.4 inch</p>	<p>NI TRAKTOR S2 MK3</p>  <p>48.7 (W) x 26.4 (H) x 6 (D) cm 19.2 x 10.4 x 2.4 inch</p>	<p>HERCULES DJCONTROL IMPULSE 300</p>  <p>48 (W) x 26.8 (H) x 5.2 (D) cm 18.9 x 10.5 x 2 inch</p>	<p>18.4"</p>  <p>18.4" laptop and small gears</p>
<p>U93010 PICK FOAM FLIGHT CASE MULTI FORMAT S</p>  <p>39.1 (W) x 31.1 (D) x 18.5 (D) cm 15.4 x 12.2 x 7.3 inch</p>	<p>PIONEER DDJ-XP2</p>  <p>33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch</p>	<p>PIONEER DDJ-200</p>  <p>37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch</p>	<p>AKAI MPC ONE</p>  <p>27.2 (W) x 27.2 (H) x 5.3 (D) cm 10.7 x 10.7 x 2.1 inch</p>	<p>NI MASCHINE MIKRO MK3</p>  <p>32 (W) x 17.7 (H) x 4.5 (D) cm 12.6 x 6.9 x 1.7 inch</p>	<p>RELOOP SPIN</p>  <p>37 (W) x 26 (H) x 9.5 (D) cm 14.6 x 10.2 x 3.7 inch</p>
<p>U93010 PICK FOAM FLIGHT CASE MULTI FORMAT S</p>  <p>39.1 (W) x 31.1 (D) x 18.5 (D) cm 15.4 x 12.2 x 7.3 inch</p>	<p>NOVATION LAUNCHKEY MINI MKIII</p>  <p>33 (W) x 17.2 (H) x 3.1 (D) cm 12.9 x 6.7 x 1.2 inch</p>	<p>NOVATION LAUNCHPAD PRO MK3</p>  <p>26.8 (W) x 26.8 (H) x 1.8 (D) cm 10.5 x 10.5 x 0.7 inch</p>	<p>NUMARK PT01 SCRATCH</p>  <p>30.2 (W) x 30.2 (H) x 10.2 (D) cm 11.9 x 11.9 x 4 inch</p>	<p>HERCULES DJCONTROL STARLIGHT</p>  <p>34 (W) x 10 (H) x 4.9 (D) cm 13.4 x 3.9 x 1.9 inch</p>	<p>HERCULES DJCONTROL IMPULSE 200</p>  <p>320 (W) x 19.5 (H) x 4.9 (D) cm 12.6 x 7.7 x 1.9 inch</p>

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U93011 PICK FOAM FLIGHT CASE MULTI FORMAT M</p>  <p>47 (W) x 40.5 (H) x 14 (D) cm 18.5 x 15.9 x 5.5 inch</p>	<p>DENON PRIME GO</p>  <p>41.1(W) x 27.4 (H) x 5.3 (D) cm 16.2 x 10.8 x 2.1 inch</p>	<p>DENON SC6000 PRIME</p>  <p>46.3 (W) x 32 (H) x 15.1 (D) cm 18.2 x 12.6 x 5.9 inch</p>	<p>DENON X1850 PRIME</p>  <p>44.8 (W) x 30.9 (H) x 11 (D) cm 17.6 x 12.2 x 4.3 inch</p>	<p>DENON SC5000 PRIME</p>  <p>32 (W) x 41.9 (H) x 13.5 (D) cm 12.6 x 16.5 x 5.3 inch</p>	<p>DENON X1800 PRIME</p>  <p>30.9 (W) x 43.4 (H) x 8.9 (D) cm 12.2 x 17.1 x 3.5 inch</p>
<p>U93012 PICK FOAM FLIGHT CASE MULTI FORMAT L</p>  <p>53.5 (W) x 46.5 (H) x 14 (D) cm 21.1 x 18.3 x 5.5 inch</p>	<p>PIONEER DJM-V10</p>  <p>46.7 (W) x 43.8 (H) x 10.8 (D) cm 18.3 x 17.2 x 4.2 inch</p>	<p>PIONEER DDJ-400</p>  <p>48.5 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>PIONEER DDJ-SB3</p>  <p>48.3 (W) x 27.2 (H) x 5.9 (D) cm 19 x 10.7 x 2.3 inch</p>	<p>DENON MC4000</p>  <p>50.5 (W) x 31.2 (H) x 6.9 (D) cm 19.9 x 12.3 x 2.7 inch</p>	<p>ROLAND DJ-707M</p>  <p>47.4 (W) x 33.1 (H) x 7.3 (D) cm 18.7 x 13 x 2.8 inch</p>
<p>U93013 PICK FOAM FLIGHT CASE MULTI FORMAT XL</p>  <p>66.7 (W) x 44.2 (H) x 12 (D) cm 26.2 x 17.4 x 4.7 inch</p>	<p>PIONEER DDJ-800</p>  <p>63.2 (W) x 33.5 (H) x 7 (D) cm 24.9 x 13.2 x 2.7 inch</p>	<p>PIONEER XDJ-RR</p>  <p>62.5 (W) x 38.9 (H) x 7.4 (D) cm 24.6 x 15.3 x 2.9 inch</p>	<p>PIONEER DDJ-SX3</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>RELOOP MIXON 4</p>  <p>65.7 (W) x 37.6 (H) x 4.5 (D) cm 25.8 x 14.8 x 1.8 inch</p>	<p>RELOOP TOUCH</p>  <p>59.4 (W) x 37.7 (H) x 4.3 (D) cm 23.4 x 14.8 x 1.7 inch</p>
<p>U93014 PICK FOAM FLIGHT CASE MULTI FORMAT 2XL</p>  <p>79.6 (W) x 45.6 (D) x 12 (D) cm 31.3 x 17.9 x 4.7 inch</p>	<p>PIONEER DDJ-1000SRT</p>  <p>70.8 (W) x 36.1 (H) x 7.3 (D) cm 27.8 x 14.2 x 2.9 inch</p>	<p>PIONEER XDJ-RX2</p>  <p>72.8 (W) x 44.4 (H) x 10.8 (D) cm 28.6 x 17.5 x 4.2 inch</p>	<p>DENON MCX8000</p>  <p>72.8 (W) x 43.3 (H) x 7 (D) cm 28.6 x 17 x 2.7 inch</p>	<p>NUMARK NS7III</p>  <p>75.4 (W) x 46.2 (H) x 12.1 (D) cm 29.7 x 18.2 x 4.8 inch</p>	<p>AKAI MPK249</p>  <p>73.7 (W) x 29.8 (H) x 9.2 (D) cm 29 x 12.3 x 3.4 inch</p>
<p>NOVATION LAUNCHKEY 49</p>  <p>77.5 (W) x 27 (H) x 9 (D) cm 30.5 x 10.6 x 3.5 inch</p>	<p>AKAI ADVANCE 49</p>  <p>75 (W) x 29.3 (H) x 8.8 (D) cm 29.5 x 11.5 x 3.5 inch</p>	<p>KORG MICROSTATION</p>  <p>77.8 (W) x 21 (H) x 8.2 (D) cm 30.6 x 8.2 x 3.2 inch</p>	<p>M-AUDIO OXYGEN 49 MK IV</p>  <p>73.7 (W) x 23.9 (H) x 9.4 (D) cm 29 x 9.4 x 3.7 inch</p>	<p>ARTURIA KEYLAB ESSENTIAL 49</p>  <p>78.4 (W) x 24.8 (H) x 7.6 (D) cm 30.9 x 9.7 x 2.9 inch</p>	

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U93016 PICK FOAM FLIGHT CASE MULTI FORMAT TURNTABLE</p>  <p>48 (W) x 41.3 (H) x 20 (D) cm 18.9 x 16.2 x 7.9 inch</p>	<p>RELOOP RP-8000 MK2</p>  <p>45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch</p>	<p>RELOOP RP-7000 MK2</p>  <p>45.8 (W) x 35.4 (H) x 14.5 (D) cm 18 x 13.9 x 5.7 inch</p>	<p>AUDIOTECHNICAL P120XUSB</p>  <p>45.2 (W) x 35.2 (H) x 14.2 (D) cm 17.8 x 13.8 x 5.6 inch</p>	<p>AUDIOTECHNICAL PW40WN</p>  <p>42 (W) x 34 (H) x 11.7 (D) cm 16.5 x 13.4 x 4.6 inch</p>	<p>TECHNICS SL-1210GR</p>  <p>45.3 (W) x 37.2 (H) x 17.3 (D) cm 17.8 x 14.6 x 6.8 inch</p>
<p>U9121BL CD PLAYER/MIXER BAG LARGE BLACK MK2</p>  <p>33.5 (W) x 45 (H) x 12.5 (D) cm 13.2 x 17.7 x 4.9 inch</p>	<p>DENON X1850 PRIME</p>  <p>44.8 (W) x 30.9 (H) x 11 (D) cm 17.6 x 12.2 x 4.3 inch</p>	<p>DENON X1800 PRIME</p>  <p>30.9 (W) x 43.4 (H) x 8.9 (D) cm 12.2 x 17.1 x 3.5 inch</p>	<p>DENON SC5000 PRIME</p>  <p>32 (W) x 41.9 (H) x 13.5 (D) cm 12.6 x 16.5 x 5.3 inch</p>	<p>RANE SEVENTY</p>  <p>44.5 (W) x 28.5 (H) x 10.5 (D) cm 17.5 x 11.2 x 4.1 inch</p>	<p>RANE SEVENTY-TWO</p>  <p>44.5 (W) x 28 (H) x 9 (D) cm 17.5 x 11 x 3.5 inch</p>
<p>U9880 DIGI TROLLEY TO GO</p>  <p>31 (W) x 39 (H) x 19 (D) cm 12.2 x 15.4 x 7.5 inch</p>	<p>PIONEER DDJ-XP2</p>  <p>33.3 (W) x 23.5 (H) x 4.4 (D) cm 13.1 x 9.3 x 1.7 inch</p>	<p>PIONEER DDJ-200</p>  <p>37.8 (W) x 20.8 (H) x 4.8 (D) cm 14.9 x 8.2 x 1.9 inch</p>	<p>AKAI MPC ONE</p>  <p>27.2 (W) x 27.2 (H) x 5.3 (D) cm 10.7 x 10.7 x 2.1 inch</p>	<p>NI MASCHINE MIKRO MK3</p>  <p>32 (W) x 17.7 (H) x 4.5 (D) cm 12.6 x 6.9 x 1.7 inch</p>	<p>RELOOP SPIN</p>  <p>37 (W) x 26 (H) x 9.5 (D) cm 14.6 x 10.2 x 3.7 inch</p>
<p>U9981 SLINGBAG TROLLEY DELUXE</p>  <p>33 (W) x 33 (H) x 20 (D) cm 13 x 13 x 7.9 inch</p>	<p>60 RECORDS</p>  <p>or</p> <p>50 12" CD SLEEVE</p> 	<p>1 CD WALLET 280</p>  <p>or</p> <p>2 CD WALLET 128</p> 	<p>AUDIO INTERFACE Universal Audio Apollo Twin</p>  <p>or</p> <p>NI Audio 6/ Komplete Audio 6</p> 	<p>FOLDABLE DJ HEADPHONE</p> 	<p>CABLES</p> 

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U9630 SLINGBAG</p>  <p>33 (W) x 33 (H) x 16 (D) cm 13 x 13 x 6.3 inch</p>	<p>50 RECORDS</p>  <p>or</p> <p>40 12" CD SLEEVE</p> 	<p>AUDIO INTERFACE Rane SL3</p>  <p>or</p> <p>NI-AUDIO 6</p> 	<p>FOLDABLE DJ HEADPHONE</p> 	<p>CABLES</p> 	
<p>U9870 TROLLEY TO GO BLACK</p>  <p>33 (W) x 33 (H) x 16 (D) cm 13 x 13 x 6.3 inch</p>	<p>50 RECORDS</p>  <p>or</p> <p>40 12" CD SLEEVE</p> 	<p>1 CD WALLET 280</p>  <p>or</p> <p>2 CD WALLET 128</p> 	<p>AUDIO INTERFACE Rane SL3</p>  <p>or</p> <p>NI-AUDIO 6</p> 	<p>FOLDABLE DJ HEADPHONE</p> 	<p>CABLES</p> 
<p>U9450 COURIER BAG</p>  <p>37.5 (W) x 30 (H) x 13 (D) cm 14.8 x 11.8 x 5.1 inch</p>	<p>40 RECORDS</p> 	<p>AUDIO INTERFACE Rane SL3/SL4</p>  <p>or</p> <p>NI Audio 6/ Komplete Audio 6</p> 	<p>CABLES</p> 		
<p>U9500 STARTER BAG BLACK/WHITE LOGO</p>  <p>32.5 (W) x 33 (H) x 17.5 (D) cm 12.8 x 13 x 6.9 inch</p>	<p>50 RECORDS</p> 